

Update procedure:

Download the file , « PDF documentation » button , the file includes the special driver to install the upgrade and the upgrade file .

1) Check the current version of the driver on your computer. You need to uninstall any version (Audio Aero 1.V.22 and/or Edel 2.26)

2) Install driver 1v56 included in this « Zip. » package (XMOS Driver 1v56 \setup.exe) and connect the USB cable to the USB 24/192 Input of your LaSource or LaFontaine device.

DO NOT CONNECT TO THE UPGRADE TERMINAL If you have any message about « Windows « approval for the download , accept installation .

3) Restart the computer.

4) Open the USB Audio control panel from Windows desktop notification area OR from : C:\Program Files\USB_Audio\AudioDriver\USBAudioCpl.exe

5) Go to the Firmware upgrade tab, select the firmware image (upgrade from 31xx to 679 _audioaero.bin) and launch the upgrade.

7) Uninstall the USB audio driver 1v56.

8) Download the latest USB audio driver for Vermeer Audio TWO from this web site (version 2.26).

<http://vermeeraudio.com/en/products/28-model-two-usb-drivers>

9) Install the new USB driver , connect the USB to the device

10) Restart your computer

11) The update procedure is finished. The USB interface do not anymore now appears as Audio Aero.